



Installation Instructions for ASG-AC2500-FG/FGNC SD2500 Foam Grips

- Lightly coat the inside of the foam grip with Rubbing (Isopropyl) Alcohol.
- Align the cutout of the foam grip to the lever (when applicable) by placing the grip over the spindle end of the SD2500.
- Firmly grip both the tool and the foam grip, and slide the foam grip up and onto the tool maintaining alignment of the cutout to the lever.
- Cycle the lever to ensure the foam grip does not interfere with the lever operation.
- Allow 24-48 hours for the alcohol to fully dissipate for a tight installation.

Note: Do not use soap or soapy water as a lubricant, these substances will not dry below the grip, leaving a loose grip on the tool.

ASG Precision Fastening Solutions

15700 S. Waterloo Rd. Cleveland, Ohio 44110 | [\(888\) 486-6163](tel:8884866163) | <https://asg-jergens.com/precision-fastening/>